

HP Laser MFP 1000 series




Reference Guide

Read this guide to get to know the printer control panel, learn how to interpret control panel light patterns, solve wireless connection problems, and find more information.

Printer control panel

NOTE: The buttons and button functions differ depending on your device model.



1 **ID Copy** button

9 **Scan** button *

15 **Cancel** button

2 **Contrast** button

10 **Menu** button

16 **Power** button/**Ready** light

3 **Scale** button or
Scan button

11 **OK** button

17 **Start** button

4 **Information** button or
Wireless button

12 **Left/Right** arrow buttons * Fax models only

5 **Control panel display**

13 **Back** button

6 **Status** light

14 **Fax** buttons: *

- Numeric keypad
- **Address book** button
- **Redial/Pause** button
- **On Hook Dial** button

7 **Fax** button *

8 **Copy** button *

Control panel light patterns



Ready



(blinking green)

Initializing or processing



(blinking orange)

Paper jam or out of paper

Printer operating environment guidelines



Keep printer out
of direct sunlight



Recommended
temperature range:
17.5° – 25° C
(63.5° – 77° F)



Recommended
humidity range:
30% – 70%



Keep printer in
well-ventilated area



Do not exceed
voltage limits

Learn more



Product support
www.hp.com/support/laser1000mfp

Printed in China

© Copyright 2022 HP Development Company, L.P.



715A2-90002

