


SPORT QUICK START GUIDE


ASSEMBLY




Simplicity
SPORT




Scan code for Owner's Manual
and product support.




Insert hose



Connect hose to wand



Attach floor tool



Attach strap

Simplicity
VACUUMS




SPORT QUICK START GUIDE

OPERATION

WARNING

Electric shock could occur if used outdoors or on wet surfaces. See owner's manual for important safety instructions.



Simplicity
VACUUMS

