

TEST BUTTON

TEST



Before each installation please reconnect the battery then press TEST button for 10 sec.



Battery test

- Blink the green LED 3 times



Alarm test

- Beep + Pre-recorded voice message + red LED blinking

LEDs STATUS

Power **Green:** Device status



- Green LED blinks every 10sec during starting sequence

Trouble **Orange:** Device trouble




- Blinks 1 time every 10sec when battery is low
- Blinks twice every 10sec when the device is on end of life mode

Alarm **Red:** Gas alarm



- Blinks every 10sec when gas concentration is above threshold
- + Pre-recorded message on speaker every minute

POWER ON SEQUENCE



STARTING SEQUENCE



+ Beep



Green LED blinks every 10sec during starting sequence



Keep Avolta in a methane-free environment during the 12 min warm-up.

Get access to :

- Avolta User Manual
- Avolta Datasheet

SCAN THIS
QR CODE

or click on this link

elichens.com/avolta-start



Visit elichens.com for more information or contact us at info@elichens.com