



SKU # 1004 384 993
Model # TY336-1911-2



Thank you!

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 25in LED Lighted Shark. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

1-855-HDHoliday (1-855-434-6543)
HOMEACCENTSHOLIDAY.COM

Parts List		
Locater	Name	Qty.
A	Hat	1
B	Halves of Head & Front Body	2
C	Halves of Rear Body	2
D	Tail and Light String	1
E	Dorsal Fin	1
F	Ventral Fin	2

Hardware List		
Locater	Name	Qty.
G	Spare Bulb	2
H	Spare Fuse	2
I	Plastic Tie	15
J	Ground Stake	4

ASSEMBLY INSTRUCTIONS
25in LED Lighted Shark

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on the ground. Many parts are connected by the lighting string that runs throughout the item. Take special care not to pull, cut or damage the lighting string. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. It is recommended to assemble parts of the product while laying flat on the ground versus standing the item up to assemble the parts. If any parts are missing or damaged do not attempt assembly but contact our customer service center.

1-855-HDHoliday (1-855-434-6543)

*Assembly of this product may require more than one person.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 4.8 Watts (0.04 Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections, exposed copper wire or other obvious damage.

Care and Cleaning

- a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections and wires. If the product is placed somewhere other than the ground it should be well secured and flat.
- b. Carefully disassemble the unit taking caution not to cut any electrical wires.
- c. Wipe the unit with a damp cloth and allow the unit to dry before storing.
- d. Store the product neatly in a cool, dry location protected from sunlight.

Troubleshooting

- a. Ensure that the floor or surface that the item sits on is flat and level
- b. Be sure to plug the item correctly to a wall outlet or a UL Listed Power Cord
- c. Ensure all parts are assembled properly per the Instruction Manual
- d. If the item does not light check for loose or broken bulbs and connections
- e. Do not plug into other electrical items
- f. If the item has multiple Light String Cords be sure to plug in all cords
- g. Check for Broken or Burned Out Fuse In Plug

Guarantee


What is Covered

The product is intended for residential seasonal use for 90 days per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipts to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse, in store display models or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday 1-855-HDHoliday (1-855-434-6543)


Diagram of Parts



ASSEMBLY


1 Assembling the Head & Front Body

Align the two Halves of Head & Front Body (B) with each other then insert the connecting rods on one half into the connecting holes on the other half and fasten together at the connecting loops with Plastic Tie(I). (Note: Fasten the adjacent parts if needed with plastic ties (as shown in the FIG).




2 Assembling the Rear Body

Align the two Halves of Rear Body (C) with each other then insert the connecting rods on one half into the connecting holes on the other half and fasten together at the connecting loops with Plastic Ties (I). (Note: Fasten the adjacent parts if needed with plastic ties (as shown in the FIG).




3 Attach the Head & Front Body to Rear Body

Insert the connecting rods on the front edge Rear Body (C) into the connecting holes on the back edge of the Head & Front Body (B) and fasten together at the connecting loops with Plastic Ties (I).




4 Securing the Tail to the Body

Insert the connecting rod on Tail (D) into the connecting holes on the end of the Rear Body (C) and fasten together at the connecting loops with Plastic Ties (I).




5 Assembling the Ventral Fins to the Body

Insert the connecting rods on each Ventral Fin (F) into the connecting holes on the sides of the Front Body (B) and fasten together over the metal frames with Plastic Ties (I).




6 Assembling the Dorsal Fin to the Body

Insert the connecting rods on the bottom of the Dorsal Fin (E) into the matching connecting holes on the top of Front Body (B) and fasten together over the metal frames with Plastic Ties (I).



7 Assembling the Hat to the top of the Head

Insert the connecting rod on the front bottom edge of the Hat (A) into the matching connecting hole at the top of Head (B).



8 Assembling the Light String and Ground Stakes

Wrap the Light String around the Body of the Shark for your desired look and secure with Plastic Ties (I) over the metal frame. Insert the clip on the Ground Stakes (J) over the metal base connecting loops then into the ground firmly.

