



Harmonics Twins S4 Smart TWS Earbuds



Welcome to the world of Portronics- It's time to enjoy true wireless sound experience with Harmonics Twins S4 Bluetooth Earbuds. We recommend you to go through the user manual for more info on working of the earbuds.

User Manual


Package Consists :

1. Harmonics Twins S4
2. Charging cable Type C
3. User Manual

Product Parameters :

Bluetooth : 5.1V
Drive Size : 13mm
Playtime : Up to 4hrs
Standby time : Up to 60hrs
Rated Input : DC5V-200mA
Frequency : 20Hz-20kHz

Product Description :



First Time Using

When using earbuds for the first time, please confirm the power of the case first. If the battery is low, please use the included cable to charge.

On/Off

Automatic power on : Open the case and the earbuds will automatically power on.

Automatic shutdown : Put the earbuds back in the case and close the cover, the earbuds will be disconnected and automatically shut down.

Bluetooth Pairing/Bluetooth Connection

To connect : Search for the earbuds pairing name (Harmonics S4) on your device and click connect to pair.

When connection is successful: the voice prompts "connected".

Auto Reconnect : After the first connection is successful, it will connect to the last paired device by default. (Note: Some smartphones need to enter "0000" as the pairing password)

Game Mode & Music Mode

Press and hold the right earbud for 2S to switch to game mode and the voice prompts "game mode". Press and hold the right earbud for 2S again to switch to music mode and the voice prompts "music mode"

Manual On/Off

In the off state, press the earbuds for 3 seconds to turn on the earbuds.

In the power-on state, long press the earbuds for 5 seconds, they will be disconnected and power off.

Overtime not connected

When the earbuds are waiting to be paired, if it fails to connect with the device within 5 minutes, it will automatically shutdown

Bluetooth effective connection distance

After the connection is successful, if the Bluetooth of the smartphone is turned off or the effective Bluetooth connection distance (10m in an unobstructed environment) is exceeded, the Bluetooth connection will be disconnected.

Key Operation

Play Music

Play/pause music: Short press left/right earbud
Previous/Next song: Double click the left/right earbud
Volume +/-: Triple click left/right earbud

Call Management

Answer a call : Short press the function key,
Reject a call : Long press the function key for 2 seconds

Turn on Game Mode

Long press the right earbud for 2 seconds.

Turn on Voice assistant(Google,Alexa or Siri)

Long press the left earbud for 2 seconds (requires smartphone to support this function)

Battery and Charging

Power Display

The status bar of your smartphone can display the battery information of the earbuds (the smartphone needs to support this function)

Charging Status

While charging the earbuds, the indicator light will have a charging prompt, and the indicator light will turn off when they are fully charged.

Charging case low battery reminder

When battery in case is low, the indicator light keeps flashing, please charge the case at the time.

Charging Case

It is recommended to use a standard charger and included charging cable to charge the charging case.

Light Status

Earbuds Indicator

- When powered on: The green indicator light is on.
- When shut down: the white indicator light is on.
- Unpaired: Green and white indicator lights flash alternately.
- Waiting for pairing: The main ear green and white indicator flashes alternately, the secondary ear green indicator flashes.
- Successful pairing: The indicator light is off.
- Music status: The indicator light is off.
- Call status: The indicator light is off
- Game mode Low battery: The white indicator flashes, and the voice prompts the lowest battery.
- Charging status: The green indicator light is always on.
- Charging completed: The indicator light is off.

Charging case indication

- Charging : The white indicator light flashes
- Charging completed : The white indicator light is always on
- Low battery : The green indicator flashes to off
- Charge the earbuds : The green indicator light is always on
- The earbuds is fully charged : The indicator light is off
- The headset is fully charged : The indicator light is off

DOS and DON'Ts

- Please put the earbuds back in the case when you're done using them.
- Do not overcharge the smartcase.
- Keep the earbuds away from extremely cold & hot places.
- Suggested temperature range 0-50 degrees. Extreme temperatures may reduce the battery life and affect product performance.
- Do not use it under thunderstorms or electric hotspots.
- Please charge the earbuds before using them, after a long time.
- Only use a dry, soft cloth to clean the earphones.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245 , 011-42413131

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3recycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste