




PYLE
PyleUSA.com

PGMSP100
Portable Wireless BT Streaming
Gramophone Speaker


Built-in Subwoofer and Rechargeable Battery, Oak Finish

USER GUIDE

Connect to the DC Power



Wireless BT Connection



Step 1: Power ON

Press and hold  3 seconds to power ON. The speaker enters into BT searching status and the blue indicator starts blinking.

Bluetooth®


My Device

Pyle PGMSP100

Step 2:

Choose the Device


Find the **Pyle PGMSP100** from the BT name list on your phone.



Step 3: Pairing Successful

The indicator light will stay blue once pairing is done, then you can play music.

AUX Connection



Basic Operation



ON/OFF/Multifunctional Button (Power Button)

- **Power ON:** Press and hold for 3 seconds.
- Quick press the button twice to disconnect the current pairing and the speaker goes into searching mode again.

Touch and Slide Key

- Short touch it to play/pause; when a call comes in or during the call, short touch it to answer the call or hang up;
- Slide to right to reject a call once a call comes in;

- Slide from the right to the left - previous track;
- Slide from the left to the right - next track.



Rotation Key

- Rotate it Clockwise to volume up;
- Rotate it Counter clockwise to volume down.

LED Operation

Power ON: The default is BT mode - Blue LED flashes quickly (in searching status). When a 3.5mm AUX cable is inserted, it goes AUX mode automatically, the green LED stays ON.

Wireless BT

- Blue LED stays ON in normal status.
- When it goes out of BT distance, it goes into searching mode and the blue LED flashes quickly. It will shutdown automatically after 30 minutes without pairing.

Searching to pair: Blue LED flashes quickly

Slide from the right to the left: The left blue LED blinks once.

Slide from the left to the right: The right blue LED blinks once.

目录

How to operate TWS pairing function

TWS Pairing

Turn ON two devices, short press  respectively and hear TWS prompt sound, both of them will automatically connect. They will connect automatically if they connected before.

The master device blue LED indicator flashes after successful pairing, another device's LED indicator will stay ON with successfully connected prompt sound, last step is searching and pairing BT then enjoy your music.

Disconnect TWS Pairing

Short press  and disconnect TWS pairing mode, blue LED indicator quickly flashes with prompt sound.

Under TWS pairing status: Short press any device, it will disconnect TWS pairing and enter standalone mode.

Attention:

BT pairing should be connected after successful TWS pairing.

What's in the Box:

Wireless BT Streaming Gramophone Speaker

Features:

- Symphonic and Powerful Sound
- Built-in Subwoofer
- Unique Gramophone Speaker
- Built-in Rechargeable Battery
- Wirelessly Stream Music via Any BT-enabled Device
- Elegant Touch Screen Control Panel for Music Selection
- Rotary Volume Control Circle
- Built-in Microphone for Hands-Free Phone Calls
- Enabled for "Twin Pairing"
- Easily Connect Two Gramophone Speakers Together

Technical Specs:

- Sound System: 3.07" Subwoofers + 1.85" Mid-Range Speakers x2
- Frequency Response: 70Hz-18KHz
- S/N Ratio: ≥75dB
- Input Sensitivity: 300mV
- Housing Construction Material: ABS + Fabric
- AUX Cable Length: (65cm, 2.13ft)
- Power Supply: 120/240V (18V/2A Power Adapter)
- Dimensions (L x W x H): 10" x 6" x 13" -inches

FREQUENTLY ASKED QUESTIONS

Q: What kind of charger should we use for the speaker?

A: All common USB chargers can be used, while we suggest the ones 5V/2A or above 2A.

Q: What if there's noise or discontinuous sound during playing?

A: The speaker can be normally used within 10m under no obstruction environment. If it is beyond 10m or with obstruction, there might be noise or discontinuous sound.

Q: Why the speaker powers off automatically after power on but no BT disconnection?

A: When there is no BT pairing in 10 minutes, the speaker will shut down automatically to reduce power consumption.

Q: Why does the speaker cannot connect the once-paired cellphone?

A: First, remove the speaker's paired name from the cellphone's BT List and then restart pairing.

Q: What is the working sequence of the speaker?

A: Default mode is BT mode but when inserted in AUX in cable, it will be AUX IN mode.

Q: The speaker doesn't start up in a normal situation.

A: Please plug-in the charger and try in a few minutes or try to press and hold power button 10-30s to reset.

Notes:

1. Before using this product, please read this manual carefully and keep it for future reference.

2. For the first use, please fully charge the product.

3. Use certified adapter that has passed national safety certification.

4. If you will not use the product for a long time, be sure to charge it once a month at least to maintain its performance.

5. Do not use this product in an extremely cold or hot environment, such as temperature beyond the range of 41°F-95°F. If using it beyond the above range, the product may stop automatically to protect the internal circuit.

6. When charging in a high temperature environment, the product may automatically stop charging to protect the battery. At this time, the charging indicator usually flashes quickly to indicate that the charging environmental temperature or the product internal temperature is too high.

7. Storage environment temperature:

-41~95°F RH <70% (recommended 77°F ±5).

Important Safety Instructions:

1. Do not disassemble or repair this speaker personally, otherwise it may cause damage or personal injury.
2. Do not use it in dusty, humid, dry, and high-temperature environment.
3. Do not place this product near heat source, or a place with direct sunlight, a lot of dust, or mechanical vibration.
4. In order to reduce the risk of fire, please do not cover this product with newspapers, table cloths, curtains etc., during use.
5. If the product has a waterproof feature, **DO NOT** exceed the nominal parameter range when using it.
6. When the product is damaged such as the power cord or plug is damaged, liquid enters or objects fall into the device, unable to operate normally or falls, it must be repaired.
7. When the product is fully charged, **DO NOT** connect it to the charger for further long time charging.
8. The maximum ambient temperature should not exceed 104°F.

California Prop 65 Warning

⚠ WARNING:

This product contains Phthalates which is known to the state of California to cause cancer birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov

PYLE
PyleUSA.com



Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

