



SERVER®

INTELLIGENT BY DESIGN®

EZ-Topper™ Short, Twin

MODEL: EZT

WITH SPOUT HEATER:

85920 COMPLETE

85713 WARMER BASE



85843 CUSTOM

WITHOUT SPOUT HEATER:

85930 COMPLETE

85714 WARMER BASE

Used with
48 fl oz pouches
with 16mm
center fitments.



Thank You

...for your purchase. This pouched topping warmer virtually eliminates product degradation and waste, so you can reduce food costs while delivering a superior product.

SIMPLIFY TOPPING MANAGEMENT—GO POUCHED



PARTS

KNOBS ON CUSTOM UNITS MAY VARY

CARAMEL KNOB

82023-024



FUDGE KNOB


82023-015



OPTIONAL:
USE KNOBS TO
QUICKLY IDENTIFY
PUMP CONTENTS

EZ-TOPPER PUMPS (2)


85820




WARMER BASE

WITH SPOUT HEATERS 85713 (SHOWN)

WITHOUT SPOUT HEATERS 85714



Units 85920
& 85713
include
MAGNETIC DECAL
84975



FOOT

07429



SAFETY



WARNING-

ELECTRICAL SHOCK COULD OCCUR

This unit must be earthed or grounded.

This requires all three prongs (terminals) on cord plug to be plugged into power source.



According to food and safety regulations, most foods must be stored and/or served at certain temperatures or they could become hazardous. Check with local food and safety regulators for specific guidelines.

Be aware of the product you are serving and the temperature the product is required to maintain. Server Products, Inc. can not be responsible for the serving of potentially hazardous product.


UNIT SETUP

**WASH ALL PARTS PROPERLY
BEFORE EVERY USE.** See page 6.


SEE SEPARATE PUMP MANUAL FOR PUMP SETUP.

1 ATTACH EACH PUMP TO EACH POUCH


- Place pouch on countertop with pouch fitment circle facing upward.
- Position pump connector directly over center of pouch fitment.
- Press pump connector down to pierce through film in pouch fitment.



Pump is fully engaged when top surface of pouch fitment touches pump connector rim.



2 INSTALL PUMPS WITH POUCHES INTO BASE




3 PLUG CORD into power source.

4 PRESS SWITCH to the "ON" position.

5 SET THERMOSTAT KNOBS

to food manufacturer's recommended serving temperature(s).

- Dial indicators use increments of 5° F.
- Thermostat maximum is 210° F/99° C.





UNIT TAKE-DOWN

- 1 PRESS SWITCH** to the “OFF” position.




- 2 UNPLUG CORD**



CAUTION- HOT


Allow unit to cool before continuing or use proper care with hot surfaces.

- 3 REMOVE PUMPS WITH POUCHES**



- 4 DETACH POUCHES**
from bottom of pumps.

- 5 FLUSH AND RINSE PUMPS**
Thoroughly rinse all inside and outside surfaces of pumps with hot water.



- 6 DISASSEMBLE AND CLEAN PUMPS.**
SEE SEPARATE PUMP MANUAL FOR PUMP CLEANING.

CLEANING



**SEE SEPARATE PUMP MANUAL
FOR PUMP INSTRUCTIONS.**

WARNING-

ELECTRICAL SHOCK COULD OCCUR

- Electrical components of unit could be damaged from water exposure or any liquid.
- Never immerse unit into water or any liquid.
- Never use any water jet or pressure sprayer on unit.
- Ensure unit is “OFF” and unplugged.

CAUTION- HOT

Allow unit to cool before cleaning.



CLEAN EXTERNAL SURFACES

- Wipe daily with a clean damp cloth.
- Dry with a clean soft cloth.
- Glass and surface cleaners approved for use in food contact areas may be used.

CARE OF STAINLESS STEEL

This warmer and accessories are constructed of stainless steel— one of the best materials for food serving and storage.


If you notice corrosion beginning on any stainless steel surface, you may need to change the cleansing agent, sanitizing agent, or the cleaning procedures you are using.

- A mildly abrasive nylon or brass brush may be used to remove any stubborn food or mineral deposits on interior surfaces of unit.
- Fully rinsing and drying all parts can help prevent corrosion. Elements and minerals in tap water can accumulate on stainless steel parts and create corrosion.
- Do not use abrasive, caustic or ammonia based cleansers.
- Do not use products containing acids, alkalines, chlorine, or salt. These agents can corrode stainless steel.
- Do not use metal scrapers or cleaning pads that could scratch surfaces.



WIRING

UNITS 85713, 85714, 85843 | 120V | USA



- | | |
|----------------------------------|-----------------------------------|
| 1 Cord Assembly | 5 Thermostat |
| 2 Bushing/Strain Relief | 6 Heating Element |
| 3 Snap-In Rocker Switch | 7 6" Wire Assembly, Green |
| 4 6" Wire Assembly, Black | 8 18" Wire Assembly, Green |

TROUBLESHOOTING

UNIT DOES NOT HEAT?

- Ensure cord is securely plugged in.
- Ensure unit is on.
- Ensure thermostat knob is set correctly.
- Ensure power is available from source.
- Do not allow any of the electrical components to get wet. Moisture may cause the unit to trip breaker or GCFI. If moisture is suspected, discontinue use. Allow unit to fully air dry.

POUCH DOES NOT EVACUATE ALL PRODUCT?

- Ensure that the pouch is properly connected with pump.

SERVER PRODUCTS LIMITED WARRANTY

2 YEAR
WARRANTY

Server Products equipment is backed by a two-year limited warranty against defects in materials and workmanship.

For complete warranty information go to:

www.Server-Products.com

GENERAL SERVICE, REPAIR OR RETURNS

Before sending any item to Server Products for service, repair, or return, contact Server Products customer service to request a **Return Authorization Number**. Merchandise must be sent to Server Products with this number. Service is extremely prompt. Typically, units are repaired and ship out within 48 hours of receipt.

Merchandise being returned for credit must be in new and unused condition and not more than 90 days old and will be subject to a 20% restocking charge. Electrical parts (thermostats, heating elements, etc.) are not returnable.

Servicing Cord: Specific tools are required for safe and proper power supply cord removal and installation. If cord must be replaced, only a representative of the OEM (original equipment manufacturer) or a qualified technician may replace cord. Cord must meet code designation H05 RN-F requirements.

NEED HELP?

Server Products Inc.

3601 Pleasant Hill Road
Richfield, WI 53076 USA



262.628.5600 | 800.558.8722



SPSALES@SERVER-PRODUCTS.COM

Please be prepared with your **Model, Part and Series Numbers**. This information and other important data is located on the lid and/or base of the unit.