

SHFiEL40 User Manual

Contents


About Mobile Router.....	2
Getting to know your device.....	2
About Key.....	2
About LED.....	3
How to use.....	3
How to Charging.....	13
Device management.....	13
1. How to login WEBUI.....	13
2. How to check or modify the Wi-Fi SSID and password.....	14
3. How to add new APN name.....	14
FAQ.....	15
1. The device cannot power on.....	15
2. I cannot access the Internet.....	16
3. I cannot find mobile router's SSID.....	16
Safety Warning.....	17



About Mobile Router

Thank you for choosing eSunFi SHFiEL40. Instantly switch between data plans with the built-in eSIM technology, it can help you to access the Internet anytime, anywhere. After the device is started, it can be used as a hot spot of Wi-Fi. Users can build their own network scenarios simply and conveniently. The device can support 10 Wi-Fi terminals and 1 USB client to access and share the mobile Internet at the same time.

Getting to know your device



About Key

Power Button Function:

1. Main function to Power On and Off
2. Long press for 2-3 seconds, will turn off the device.



About LED



1. Traffic operator name
2. WiFi SSID/Key
3. Signal strength
4. WiFi indicator & connected device
5. SIM card indicator
6. Battery level

How to use

Use physical SIM card to access the internet:

1. Insert SIM card and power on.
2. After power on, the device will try attaching network automatically.
3. Connect client to mobile router (support Wi-Fi ,USB) .

Use eSIM plans to access the internet

1. Download the eSIM manager for scanning the QR code:


Andriod: download eSIM Manager in Google Play Store

iOs: download eSIM Manager in Apple Store

2. Buy eSIM plan from <http://go.linksfield.net/login?partnerCode=P002379>, or from other eSIM data providers
3. Power on the SHFiEL40 and login the WEBUI by 192.168.0.1, the default username and password are both "admin". Make sure SHFiEL40 is in eSIM mode on



Settings-->System-->Reboot





If not in eSIM mode, please select eSIM mode and reboot SHFiEL40


4. How to download eSIM profile from Android smartphone

4.1 Enter the main page and Add the eSIM Mifi


Note: You can also connect SHFiEL40 via WiFi, but the mobile phone needs to open the cellular network to ensure that the mobile phone network is not faulty when downloading the eSIM plans.



4.2 Tap the “SHFiEL40” and Choose Bluetooth connection







4.3 Add device and enter into the device profile management page



4.4 After selecting current device, scanning QR code and starting up download and activating Profile by pressing “Activate” button . (The provisioning and activate



process can be configured separately if customer required)





4.5 Operation video reference website link: <https://youtu.be/vLvybdFAGBE>





5. How to download eSIM profile from iPhone

5.1 Enter the main page and Add the eSIM Mifi





5.2 Tap the “Test Device” and Choose Bluetooth connection









5.3 Add device and enter into the device profile management page







5.4 After selecting current device, scanning QR code and starting up download and activating Profile by pressing "Activate" button . (The provisioning and activate process can be configured separately if customer required)









6. Switch eSIM profile









7. Disable eSIM profile





8. Delete eSIM profile





A. Connect through Wi-Fi

- Click view available wireless networks in your devices.



- Choose Wi-Fi name (SSID)

Default SSID can be found on the box or back casing of Mobile router.

- Input the password

Default password can be found on the box or back casing of Mobile router.



B. Connect through USB

- Connect Mobile router and computer with USB cable
- After a few seconds of automatic installation, your computer can share mobile router's network .

How to Charging

1. Charging through Power adapter
2. Charging through USB connected to computer or power bank

Note:


1. Please use the 5V/1A power adapter to power the device.
2. The charging time of charging through computer or power bank maybe longer than charging through Power adapter.



3. The charging temperature of the product is between -10 °C and 60 °C , please keep the device within this temperature rang when charging.

Device management


1. You can manage your device by login the WebUI(192.168.0.1). The default username and password are both "admin".



A "Log In" dialog box with a title bar containing a close button. It contains two input fields: "User name:" with the text "admin" and "Password:" with masked characters ".....". At the bottom right are two buttons: "Log In" and "Cancel".

2. How to check or modify the Wi-Fi SSID and password

It can be modified on **settings-->WLAN**



A screenshot of a web browser showing the "WLAN Basic Settings" page. The address bar shows "192.168.0.1/html/wlanbasicsettings.html". The page has a navigation menu on the left with options like "Quick Setup", "Dial-up", "Internet WLAN", "WLAN", and "WLAN Basic Settings" (which is selected). The main content area is titled "WLAN Basic Settings" and contains instructions for SSID and password. It includes input fields for "SSID:" (containing "MIFI_2.4G_092614"), "802.11 authentication:" (set to "WPA2-PSK"), "Encryption mode:" (set to "AES"), and "WPA pre-shared key:" (masked). There are also checkboxes for "Show password on device", "SSID Broadcast:" (set to "Enable"), and "WIFI switch:" (set to "Enable"). An "Apply" button is at the bottom right.



不安全 | 192.168.0.1/html/ac_setting.html

Home | Statistics | SMS | Update | **Settings** | More

WLAN AC Settings

Quick Setup

- Dial-up
- Internet WLAN
- WLAN**
 - WLAN Basic Settings
 - WLAN AC Settings**
 - WLAN Advanced Settings
 - WLAN MAC Filter
 - DHCP
 - Set DNS server manually
 - DHCP Static IP
- Security
- System

Name SSID (Service Set Identifier): Enter a character string, of up to 32 characters in length, as the name for your wireless local area network (WLAN).

LCD interface may omit some long SSID and password content

If the encryption mode is set to WEP or TKIP, a wireless network adapter working in only 802.11n mode may not be able to access the device.

☒ Show password on device

SSID:

802.11 authentication:

Encryption mode:

WPA pre-shared key:

☐ Show password

SSID Broadcast: ☒ Enable ☐ Disable

WiFi switch: ☒ Enable ☐ Disable

3. How to add new APN name

Enter **Settings-->Dial up-->Profile management**,click **New Profile**

不安全 | 192.168.0.1/html/profilesmgr.html

English | Help | admin | Log Out

Home | Statistics | SMS | Update | **Settings** | More

Profile Management

Quick Setup

- Dial-up
 - Mobile Connection
 - Profile Management**
 - Network Settings
- Internet WLAN
- WLAN
- Security
- System

Profile name:

User name:

Password:

APN:

Dial-up number:

Authentication:

Network Mode:

Connection Mode:



New Profile

Profile name: ← enter profile name

User name:

Password:

APN: ← enter APN name

Authentication: ▼

Dial-up number:

Network Mode: ▼

Connection Mode: ▼

Save **Cancel**

After entering the APN name, click **Save**.

For more instructions please refer to the help document

The help document can be found on WebUI--**help**

FAQ

1. The device cannot power on

Please charging your device firstly, and make sure that the environment temperature is between -10°C and 60°C.

2. I cannot access the Internet

- Check whether the SIM card is inserted correctly(new eSIM plans been enabled) and that good signal strength.
- APN setting is correct according to the new eSIM plans
- Check whether the clients are connected to the mobile router correctly, either via the correct SSID over Wi-Fi or via USB.
- Ensure your SIM card(eSIM plan) has adequate data balance available.

If the problem still persists, please get in touch with your service provider.

3. I cannot find mobile router's SSID

- Make sure that device is power on



- Short Press power key to wake up Wi-Fi(maybe the device went into sleep mode)
- If the issue still exist , please press reset button to restore the factory settings.

4. I cannot connect mobile router through Wi-Fi

- Make sure the SSID and password is correct(it's case sensitive)
- Make sure you have not set MAC Filter.
- If the issue still exist , please press reset button to restore the factory settings.

5. I forgot the Wi-Fi SSID and password

Don't worry , you can press reset button to restore the factory settings, and the default SSID and password can be find on the back casing of mobile router.

6. What can I do if my mobile router is not getting charged

- Check whether the charger and USB cable are working properly. It is recommended to use the original charger and USB cable.
- Check if the environment temperature is too high or low. Device only can be charged when temperature is between -10℃ and 60℃.

7. How do I view the device's help document?

Connect the device through Wi-Fi or USB, open the management page of the device(192.168.0.1), and click help to view the help document, which contains the introduction of all functions of the device.

Safety Warning

1. Please use the 5V/1A power adapter to power the device.
2. When mobile router is working, don't place metal objects in the use range to avoid signal interference.
3. Do not open and touch the inner area of your device as it may affect your device performance.
4. Magnetic stripe cards(including credit cards, phone cards, bank passbooks, etc.) may be damaged by magnetic field.
5. If don't use mobile router for a long time, please take out the battery.



FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a appropriate separation distance between the user's body and the back of the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. Use only the supplied or an approved antenna.

