



K9 Pro DUO Temperature Stand Instructions



Insert tube into base (use the tube WITHOUT the horizontal slit at the top). Be careful to line up the holes



Insert a long pin into each hole. The pin should insert until it is flush with the metal.



With a screwdriver, attach the short screw into the threaded part of the long pin.



Attach the second tube, sliding it OVER the top of the first tube you attached. Do NOT use the tube with the two vertical holes at one end.



Again, insert a long pin into each hole and attach a short screw into the threaded part of the long pin.



Insert tube into the second tube, making sure the horizontal slot is at the TOP. Use the long pins to secure the tube.



Attach the final tube with the vertical holes OVER the top of the third tube. Make sure the holes are at the top. Use the long pins to secure the tube.



Attach the dispenser mounting plate with the pre-attached mounting pins facing out. Use the shorter pins to secure the mounting plate to the stand.



Slide the drip tray through the horizontal slot at the top of the third tube.



Use the shorter pin to secure the drip tray to the stand.



Slide the Temperature/Dispenser onto the pins of the mounting plate. FIRMLY push down until the dispenser unit does not slide off.

