

LAMP ALLE LUX 5

Technical specifications:

Number of UV LEDs: 24

Max Power: 48W

Wave length UV: 365+405nm

Power: Rated input: 100/240V 50/60Hz 1A

Size: 220 x 195 x 105mm lamp model : SUN 5

No. Certificate: MOSTCN19081612

MOSTCN19081613

Cures UV/Builder/LED gels.

Instructions:

1. Infrared motion sensor.
2. Power indicator
3. Time switch button – 10s
4. Time switch button – 30s
5. Time switch button – 60s
6. Reduced heat mode (99s) / ON/OFF button
7. Power supply



Operating instructions:

1. Connect the device to the power supply.
2. To turn on the lamp, hold the ON/OFF button for 1-2s. If the display the countdown starts, press the button again to enter the standby mode.
3. You can select one of the available timer options 10s/30s/60s/99sec
In 99s mode, the heating power is gradually increased so that you can reduce the effect of nail plate burning caused by gel curing.
4. You can also start without choosing the time. To do this, put your hand in the device, and the heating will start automatically when the sensor detects movement. The maximum operating time is 120 s.

Warning:

Use the correct voltage for the lamp. Protect the device from contact with water and others fluids.
Do not use the lamp: - In damp rooms - If the power supply is damaged
- If the device or connection cable is damaged - If the timer buttons are not working
The device should not be left in operation for more than 60 minutes, as this may reduce its lifetime. When the device temperature is too high, the status „07p” will appear on the display. To resume operation, wait until the message disappears.

If you notice sudden changes on your skin, consult a doctor immediately. The device is designed for indoor use.

KEEP OUT OF THE REACH OF CHILDREN.

