



Enabling Industrial IoT

SNYPER·LTE+ / SPECTRUM V1 / V2 (EU/USA) QUICK START GUIDE

SNYPER-LTE+ / Spectrum Case Contents

- 1 SNYPER-LTE+ or SNYPER-LTE+ Spectrum
- 2 PSU with 4 Adapter Heads
- 3 0.5M USB Cable
- 4 USB Car Charger
- 5 Omni-directional Antennas – General Purpose (Blue) and 2600MHz (Silver/Grey)*
- 6 LiveSCAN Directional Antenna (Spectrum model only)
- 7 1.5M Extension Cable for LiveSCAN Antenna (Spectrum model only)

*2600MHZ (Silver/Grey) antenna supplied for EU model only



www.siretta.com

+44 (0)118 976 9000

Rev 1.3

Siretta Ltd, Basingstoke Road, Spencers Wood, Reading, Berkshire, RG7 1PW, UK



· FIRST STEP BEFORE USE

- **BATTERY CHARGE**
Charge the unit for 4-6 hours or until the red charge light is extinguished.
- **SET TIME**
 - 1) Power up the SNYPER 
 - 2) Select 'Setup' from the 'Main Menu'
 - 3) Select 'Set Time'
 - 4) Use the keypad arrows to set date/time

Use  **BACK** key to exit
- **SOFTWARE UPDATE**
Go to <https://www.siretta.com/snyper-plus> to check for latest software.
- Your SNYPER is now ready to use



· SURVEY

- **NEW SURVEY OPTIONS**
 - 1) Select Full, LTE, UMTS or GSM*
 - 2) Press  to start survey
 - 3) Leave device to complete survey

*The SNYPER-LTE+ (USA) does not survey the GSM band.
- **POST SURVEY OPTION 1**
 - 1) Select 'Show Results'
 - 2) Press  to start LiveSCAN (Spectrum only)

Use  **BACK** key to exit
- **POST SURVEY OPTION 2**
 - 1) Select 'Show Summary'

Use  **BACK** key to exit
- **POST SURVEY OPTION 3**
 - 1) Select 'Save Results'

This is only necessary if Auto Save is off

Use  **BACK** key to exit

· SAVED RESULTS

- **STORED SURVEY**
 - 1) Select results file you wish to view
 - 2) Select 'Show Results', 'Show Summary' or 'Export Results'

Use  **BACK** key to exit

· SETUP

- **Language:** ENG/DEU/FRA/ITA/SPA
Display: Screen brightness and text colours
Auto off: Auto switch off and dimming
Documents: File types and Auto Save
Sound: On/Off
System: Mode and region of operation
Set Time: Set date and time
Reset Menu: Return to default settings

Use  **BACK** key to exit

· ABOUT

- Key reference parameters about the device

Use  **BACK** key to exit

· PC CONNECT

- **PC CONNECT**
 - 1) Connect USB cable between device and PC
 - 2) Select ON to enable USB connection, begin results download
 - 3) Copy files required to PC
 - 4) Select OFF to disable connection

Use  **BACK** key to exit

You can then view results files on your PC

For safety documents, please visit:
<https://www.siretta.com/safety/>