




(1) How to program your Admin Fingerprint Lock


1 Start with lock shackle closed





2 Press gently your finger on the sensor and keep pressing, you will hear a few “Beeps” and it will open the lock, keep pressing until you see a blue light, then release your finger, You will see a green light blinking.




Press gently your finger on the sensor and release, each time you will hear a “Beep” and see either a blue light, or a red light.



3 You need five (5) blue lights to program the lock, if you get a red light, it means that the lock does not recognize your finger, So keep pressing and releasing...
...until you get 5 blue lights and hear a long “Beep” and see a stable green light.
Then you are done. Congrats.




(2) How to collect the 2nd to the 10th Fingerprint



Remarks

1. The first and second fingerprints are the admins by default
2. One of the admins fingerprint will be needed to authorize when adding fingerprints

(3) How to delete Fingerprint and reset the lock



Thank you for your purchase.

We hope you will enjoy your new TOKK™ Fingerprint Lock.

If you encounter any issues setting it up and/or using your new product, please do not hesitate to call us and we will be very happy to help you. You can also watch our step-by-step demo video on our website: www.tokktech.com

Our Customer service email is contact@predtechnologies.com

Our Customer service phone number is +1 (858) 999-2114 ext 1

PRED
TECHNOLOGIES™