

DLA+ 2.0 WIRELESS | QUICKSTART GUIDE



NOTE:

Adapter is powered by the vehicle and must be connected to operate.

INSTALL DRIVERS:

- 1 Close running applications.
- 2 Users can download adapter drivers online by visiting: www.noregon.com/adapter-drivers and clicking the "Instructions and Driver Download" button from the **DLA+ 2.0 Wireless Adapter** section of the adapter driver landing page.
- 3 Once the download is complete, launch the installer and follow the prompts.

USB CONNECTION:

- 4 Plug the USB cable into the USB port on the PC.
- 5 Connect the other end of the USB cable to the port labeled Computer on the DLA+ 2.0 Wireless Adapter.
- 6 Connect the diagnostic cable to the 26-pin connector on the DLA+ 2.0 Wireless Adapter.
- 7 Attach the diagnostic cable's connector to the diagnostic port on the vehicle.

WIRELESS CONFIGURATION: Refer to the DLA+ 2.0 Wireless Configuration section of the DLA+ 2.0 Adapter Family User's Manual for information on configuring the adapter for wireless connectivity. Find the User's Guide by clicking on the Windows Start button, then select All Programs ➔ Noregon ➔ DLA+ 2.0 Wireless Adapter and click the DLA+ 2.0 Adapter Family User's Manual menu item.

QUESTIONS?

Call: (855) 889-5776

For driver updates & more, visit:

WWW.NOREGON.COM

