

⚠ Important Notes

- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.
- Do **NOT** stare directly into the apertures of the laser.

Description

- ① **On/Off Button** – press to turn laser measure on, hold to turn off
- ② **BLE On/Off Button** – press to turn Bluetooth on/off on laser measure
- ③ **Setting Button** – press to enter laser setting



GLM50C

GLM165-27

Included in the box

- Laser Measure 1X
- Fabric Pouch 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader
- Android: MultiGage Reader
- Windows: MultiGage Reader (BLE Dongle Required)
- iOS app can be directly downloaded from the App Store for FREE.
- Android app can be directly downloaded from the Google Play Store for FREE.
- Windows software is available at motionics.com/download.

Quick Start

- Insert 2x batteries into laser measure for a first-time use.
- Turn on laser measure and Bluetooth.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run software (refer to compatible software section for download, and launch).
- For a first-time use, device activation is required using code printed on device.
 - On iOS, go to New Measurement>More>Setting, and enter activation code into Custom Codes field.
 - On Android, go to Menu>Settings, enter activation code into Custom Codes field and press Save.
 - On Windows, go to Settings>Activation>Custom Activation Codes, enter activation code, press Add Code then Save.
- Tap Pair button in software to enter pairing page.
- Wait for the software to finish scanning nearby devices, then select "**Bosch GLM50C xXXXX**" / "**GLM165 - 27C(G) xXXXX**" to connect.
- Connection may take a few seconds. Once paired, readings show in software.
- To turn on/off laser, do the following:
 - On iOS/Android, tap device name, toggle **Activate Laser** switch and press Save.
 - On Windows, go to Gages, tap setting icon of laser measure, toggle laser switch.

