



USER MANUAL

Smart Watch

Downloading the App


Scan the following QR code, download and install the App.



Scan QR Code and Download

Charging and Active

Charging the device to active before the first time using;
To charge your device, plug the charging cable into the adapter or USB port on your computer.



Pairing

Open the App and set up your profile

Go to the 「Device」, Click 「Add a Device」

Choose your device on the scanning list

Finish

Long press the 「time page」 on your device, go to the detail page. The MAC address on the detail page could help you identify your device on the scanning list.

Use the Touch Screen




On the Main Page:

Swipe Up/Down to the main menu page.

Swipe right/Back to previous


Swipe Up

Swipe Down



Click

Swipe Right



Smart Watch Features

< STEP

8026

5.62 206

KM DISTANCE KCAL CALORY

Sports

Smart Watch automatically tracks Steps taken, Calories burned, Distance traveled and displays on the screen.

NOTE: Your movement stats reset to zero at midnight.

< SLEEP

08H26M

06:04 02:02

DEEP LIGHT

Sleep

If you keep wearing Smart Watch in your sleep, it can provide the hours slept and quality of sleep stats on both the screen and the APP.

NOTE: Sleep stats reset to zero at 8:00 pm.

Smart Watch Features

< HR

82 AVG

CLICK TO MEASURE

Heart Rate Test

Tap the heart rate icon to start measuring your heart rate.
On the heart rate page, It can show the heart rate measured data of the last times.

< TRAINING

WALKING

RUNNING

CYCLING

Training

Tap the training icon on the menu to start a new training measure recording, there are 8 sport modes to be chosen.

The last training recording will be shown on the training page.

Smart Watch Features

< BP

140

90

60

CLICK TO MEASURE

Blood Pressure Test

Tap the blood pressure icon to start measuring your blood pressure.
On the blood pressure page, It can show the blood pressure measured data of the last times.

< SpO2

100

95

90

CLICK TO MEASURE

SpO2 Test

Tap the SpO2 icon to start measuring your SpO2.
On the SpO2 page, It can show the SpO2 measured data of the last times.

< WECHAT

JACK: WHERE YOU BEEN?

...

Messages Reminder

The device can sync incoming notifications from Twitter, Facebook, Whatsapp, Instagram etc. Recently 3 messages can be stored.

Note: You can switch of/off the incoming notification in the APP.

Smart Watch Features

< SHUTTER

CLICK TO MEASURE

Remote Shutter

After connecting the device can remote control the camera on your phone.

< TIMER

02:34.39

CLICK TO MEASURE

Silent Alarms

Set up the alarm on the APP, the device will vibrate to remind on time.

Smart Watch Features

< MUTE

BRIGHTNESS

SWITCH STYLE

Other Features

Other features include mute mode, brightness adjustment, factory reset, and power off.

< WALK AROUND!

WALK AROUND!

Remind to Move

The device will vibrate to remind you to make a relax after 1 hour sitting.
Note: You can switch on/off the feature in the APP.

Getting to Know Your Device

1.Using in Wet Conditions

Your device is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout.
NOTE: Do not swim with your Smart Bracelet. We also don't recommend showering with your wristband; though the water won't hurt the device, wearing it 24/7 does not give your skin a chance to breathe. Whenever you get your bracelet wet, dry it thoroughly before putting it back on.

2.Using Quick View

With Quick View you can check the time or the message form your phone on your Smart Bracelet without taping. Just turn your wrist towards you and the time screen will appear for a few seconds.

General Info & Specifications

1.Environmental Conditions

Operating temperature: 14°F to 122°F (-10°C to 50°C)
Non-operating temperature: -4°F to 140°F (-20°C to 60°C)

2.Size

Fits a wrist between 5.5 and 7.7 inches in circumference.

3.Disposal and Recycling

Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle Smart Bracelet and accompanying components. Do not dispose of Smart Bracelet with common household waste, the Smart Bracelet unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility.
For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation. RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

