



Wireless Motion Sensor User Manual



Please read this manual carefully
before using the product.



Motion Sensor



The wireless motion sensor detects movement up to 12ft* away. It alerts the pager of a person's activities when the person interrupts the motion sensor's infrared field, as long as the motion sensor and the pager are within 300ft* of each other. It is applicable in facilities such as bedroom, doorway, near stairs etc.

****Note: The range of wireless devices and detection distance may vary and be dependent on your specific environmental conditions.***




Product Specifications

- Frequency: 433MHz
- Operating Range: Up to 300ft* (in open area)
- Range Detection Area: see Picture A*

****Note: surrounding metal walls or other electronic devices might interfere or affect the signal range. Fully extend the antenna for the most optimal signal range.***

- Power Supply: AA battery x 3
or 6-12V AC adaptor



Picture A

Features

■ Easy & Simple to Use

The motion sensor detects movement and alters caregiver or staff when a person interrupts the motions sensor's infrared field.

■ Flexible on Installation


Motion sensor may be mounted next to a bed to indicate when a person arises or placed by a doorway to indicate when a person is approaching the doorway.




Installation - Montion Sensor

If you use screws to fix the motion sensor to a permanent position, you will need to separate it and bracket before you screw the bracket to a fixture.


1. Rotate the motion sensor in it's bracket 90 degrees so that it is facing the ceiling.
2. Apply gentle pressure to one arm of the bracket so that the motion sensor can easily pop out.



Mount the Motion Sensor




A. Wall Mount with Double Sided Tape
The motion sensor may be affixed to most smooth, clean surfaces with the included double sided tape.



B. Wall Mount with Screws
The motion sensor may be more securely mounted to walls or headboards with the included screws. Use the recessed holes for screw placement on the motion sensor.



Setup - Montion Sensor




1

Insert 3 new AA batteries into the motion sensor or a 6-12V DC adaptor.

2

Flip switch on front of the monitor to "ON" position.



3

Test the motion sensor by waving a hand in front of the infrared sensor. If the green indicator flashes, it means the sensor is working correctly and a signal is being sent by the motion sensor.

Green when motion detected



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

