

O-Cedar®
EasyWring™ Refill



Refills available

For best results replace refill every 3 months

Repuestos disponibles

Para mejores resultados, cambie los repuestos cada 3 meses

O-Cedar®
EasyWring™ Power Refill



Find out more about our full assortment at ocedar.com



People have trusted O-Cedar® for over 115 years to help get their cleaning jobs done right. If you are not completely satisfied, please contact us through our website, Facebook page or by calling 1-800-543-8105.

a brand of
FREUDENBERG


©2021 Freudenberg Household Products LP
Attn: Consumer Affairs, 2188 Diehl Road, Aurora, IL 60502
1-800-543-8105 EPA Est. 99642-IL-1

O-Cedar®

MICROFIBER EASYWRING™


SPIN MOP & BUCKET SYSTEM
SISTEMA DE CUBETA Y TRAPEADOR GIRADOR

Use & Care Guide
Guía de uso y cuidado



*Removes, does not kill, over 99% of E.coli and Staph. aureus from pre-finished hardwood flooring and ceramic tile using tap water, as tested at an independent accredited lab.

TO ASSEMBLE / PARA ENSAMBLAR



INSTRUCTIONS / INSTRUCCIONES



Fill bucket to max line

Do not use bleach

Llene la cubeta hasta la línea máxima
No usar bleach



Place mop inside bucket

Coloque el trapeador dentro de la cubeta



Place wet mop inside wringer

Coloque el trapeador húmeda dentro del exprimidor



Loosely hold handle vertically to allow mop to spin

Sostenga la manija en sentido vertical sin apretarlo para permitir que el trapeador gire



Push pedal to customize moisture level

Presione el pedal para ajustar el nivel de humedad



Store bucket in dry conditions. Do not expose to excessive sunlight.

Guarde la cubeta en condiciones secas. No exponga en exceso a la luz del sol.

TO WASH* / PARA LAVAR*



TO REMOVE

Step on strands and tilt handle away from your foot to separate base from mophead

PARA QUITAR

Pise los soportes del trapeador e incline la manija hacia el lado contrario de su pie para separar la base de la cabeza del trapeador



TO WASH*

Machine or hand wash in warm water and lay flat to dry

**Do not use fabric softeners or bleach*

PARA LAVAR*

Lávelo a máquina o a mano con agua tibia y extiéndalo para secar

**No use suavizante o bleach*



TO REPLACE

Align microfiber mop head with base and push down until it snaps securely in place

PARA REEMPLAZO

Alinee el cabezal del trapeador de microfibra con la base y presione hacia abajo hasta que encaje de manera segura en su lugar

