

RONDA mecano

– R150

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.

An automatic movement uses the natural movements of the wearer's arm to wind the mainspring of the movement via the built-in oscillating weight. In order for a watch with a RONDA R150 automatic movement to run self-sustainingly, RONDA recommends a daily wearing time of 12 hours. If the watch is worn for a shorter period of time, it is advisable to wind up the movement by turning the stem a few times, especially if the wearer is only slightly active.

If the movement has come to a standstill, it is recommended restarting the movement by turning the adjusting stem 16 times with the crown in position I.

The automatic movement RONDA R150 has a power reserve of at least 40 hours when fully wound. If the watch is not worn or moved for more than 40 hours, it will stop after this time and must be wound up again.



Cal. R150

Crown A

Pos. I Position of rest (watch running)

Winding while stopped

The maximum power reserve can be restored by turning the crown clockwise around 30 times.

Pos. II Quick-change correction for date

- Pull the crown out to position II (watch still running).
- Turn the crown anticlockwise until the required date appears.
- Push the crown back into position I.

Pos. III Setting the time

- Pull the crown out to position III (watch stopped).
- Turn the crown, until the current time is displayed (remember the 24-hour cycle).
- Push the crown back into position I.