




DLA+ WIRELESS


VEHICLE INTERFACE

QUICKSTART GUIDE



NOTE:

Adapter is powered by the vehicle and must be connected to operate.



*Ensure that the USB cable is firmly seated into the adapter's USB port

INSTALL DRIVERS:

- 1 Close running applications.
- 2 Users can download adapter drivers online by visiting: www.noregon.com/adapter-drivers and clicking the "Instructions and Driver Download" button from the **DLA+ 3.0 - Wireless Adapter** section of the adapter driver landing page.
- 3 Once the download is complete, launch the installer and follow the prompts.

USB CONNECTION:

- 4 Connect the D89 end of the USB cable to the port labeled "Computer" on the DLA+ Wireless Adapter.
- 5 Plug the other end of the USB cable into the USB port on the PC.
- 6 Connect the diagnostic cable to the 26-pin connector on the DLA+ 3.0 Wireless Adapter.
- 7 Attach the diagnostic cable's connector to the diagnostic port on the vehicle.

WIRELESS CONFIGURATION: Refer to the DLA+ 3.0 Wireless Configuration section of the DLA+ 3.0 Adapter Family User's Manual for information on configuring the adapter for wireless connectivity. Find the User Manual by clicking on the Windows Start button, then select Noregon ➔ "Noregon DLA+ 3.0 Adapter" and click the "DLA+ 3.0 Adapter Family User Manual" menu item.

QUESTIONS?

Call: (855) 889-5776

For driver updates & more, visit:

WWW.NOREGON.COM

